

Installation guide for your wall art



Frame type: Aluminium Composite board

Option 1: Screw with colour caps. We advise 2 person fit.



*Suitable for any wall indoor or out + timber surfaces such as fences.

- This fixing should be installed in the frame part of the image. Aim for each corner equally.
- We recommend allowing 30-50 mm clearance from the edge of the frame in each corner. Measure and mark the centre for each drill hole x 1 for each corner. Total 4 marks should be made for 4 fixings. All looking evenly spaced. On the printed side of the board.
- *Place the image on wood to allow for you to drill through the mark points and not damage the material below.
- Now select a drill bit that is + 2mm larger than the screws you intend to use.
- **Important:** Ensure the drill hole is + 2mm larger than the actual screw being used. This is to allow the composite material to expand and contract when exposed to heat or cold. This applies to both indoor and outdoor.
- Now line up the frame on the wall. Use a spirit level to ensure the frame will be level. Once happy with the location. Mark the 4 holes with a pencil. These will guide the fixings so all finishes level.
- *If you are drilling into stone/ masonry. Use a raw plug and fix into these marked points prior to the next stage.
- Place the screw cap base on the surface of the frame. Then feed the screw through.
- Now line up the frame with the marks on the wall.
- Screw the picture to the surface of the wall. Slowly. Until the screw is within the base of the cap. Not tight.
- **Important:** Do not over tighten the fixing screw into the frame surface. Allow some movement.
- To finish. Clip the cap shut to hide the screw. And enjoy!

Option 2: Sticky pads. We advise 2 person fit.

*Only suitable for indoor or sheltered walls. That are smooth and solid.

*Ensure the surface of the wall is Dust free, dry, clean and not peeling/ loose.

- Line up the frame to its desired location and mark on the wall each corner to give you a future reference point.
- Place the print image face down on a clean/ smooth surface (or use the protection wrap)
- Dry wipe the back of the frame (silver side) to remove any contamination.
- Remove the peel from one side of the pad at a time.
- Place 8 sticky pads onto the back of the frame. Ideally located evenly spaced apart in each corner + centrally.
- Now peel off the remaining protectors to expose the sticky surfaces.
- Line up the frame to its desired location. *Do not touch the wall.
- Once happy and lined up. Press the frame against the clean + dry wall and hold in place for 2 minutes. Pressing firmly in the areas you placed the pads.
- Now release the frame and all should stay in place.

***Please note.** We do not take any liability for the sticky pads installation or the longevity of this fixing. If in doubt. Use the above screw method.